## **Preview**



Thanks how to plot it.

Commented Tokoro (/users/Tokoro) 5

(/users/Tokoro/reputation)


(/users/Tokoro)






@dharr (/questions/233595-How-To-Plot-Nnn-3D-Mesh-By-Maple#answer284480) Thanks a lot. When I chage n to 20, Maple takes a lot of time to plot it. Is there any way to plot more fast?


Using your answer I can make electric circuit resistor mesh probrems. Each element of plot to plot is 1 ohm resistor.




1 ohm.




1.5ohm




1.8571 ohm




3.1326 ohm




5/6 ohm



1.0238 ohm



1.1232 ohm



1.3227 ohm.

## 

Subscribe: